Digital Video Mixer Service Manual







01/27/95



1.5





FATHER BOARD TROUBLE SHOOTING GUIDE THROUGH JAN. 29, 1995

OBLEM	COMPONENT	LIKELY CAUSE
DIO	Q1	DEFECTIVE OR SOLDER SHORT
	1.2	MISSING
	Q59	DEFECTIVE
	R107	MISSING OR POORLY SOLDERED
	R111	MISSING
	R113	DEFECTIVE
N'T ADJUST	Y1	DEFECTIVE
ANNEL COLOR	Q31	DEFECTIVE OR POORLY SOLDERED
	JACK	POORLY SOLDERED
	Q29	POORLY SOLDERED
	C190	POORLY SOLDERED
	C201	MISSING
	U27	DEFECTIVE OR POORLY SOLDERED
IANNEL COLOR LOCK	Y3	DEFECTIVE
	R253	POORLY SOLDERED
	Y2	DEFECTIVE
,	C145	WRONG VALUE
	D31	DEFECTIVE OR MISSING
	C141	REVERSED OR WRONG VALUE
160	R254	POORLY SOLDERED
ANNEL HALF THERE	U30	DEFECTIVE
HANNEL MISSING	C221	TRACE DAMAGED OR WRONG VALUE
MINEL IMPORTA	D13	DEFECTIVE
	Y2	DEFECTIVE
	D23	DEFECTIVE
	R186	POORLY SOLDERED OR TRACE DAMAGED
	U18	DEFECTIVE OR POORLY SOLDERED
HANNEL NOISY	D31	DEFECTIVE OR REVERSED
	R229	POORLY SOLDERED
	U26	DEFECTIVE
	U27	POORLY SOLDERED
	Y2	DEFECTIVE
HANNEL OVERSIZED	U30	DEFECTIVE
HANNEL SCRAMBLED	JACK	POORLY SOLDERED
	U26	DEFECTIVE OR POORLY SOLDERED
5.44		

Mixer Father Board Tune Up Procedure PROC-0055-01 Revision A; 02/27/95

- 4.2.0.4. Half-n-half fixed test begins. This displays digital, time base corrected, channel "B" in top half of the screen and channel "A" in bottom half of the screen. Input video source is Y/C-1.
- 4.2.1. Adjust Channel A Chroma A to D:
- 4.2.1.1. While watching the monitor display adjust the blue pot, RV4 until the vertical lines on the video disappear. This pot will adjust only the bottom half of the monitor display.
- 4.2.2 Adjust Channel B Chroma A to D:
- 4.2.2.1. Adjust the second blue pot RV3 and follow the same adjustment procedure as for the first blue pot. This time the top half of the monitor will be adjusted. Turn the pot until the vertical lines disappear.
- 4.2.2.2. Continue running this MFG Test [01] to be used for matching the Luminance.
- 4.3. Match Luminance of Channel A to B: While watching the monitor display, adjust RV2 so that the horizontal split line disappears in the middle two Dark Gray Title and background.
- 4.4. Match Horizontal Position of Channel A to B (Left/Right Shift)
- 4.4.1. While watching the monitor display, adjust RV1 so that the vertical edge of the lines separating the letter "P", "R" or "B" or Box line up above and below the horizontal split line.
- 4.4.2. Press the <OK> key to exit back to the Top Level MFG Test Menu.
- 4.4.3. Power off the board, and remove cable connections.

Tune-up procedure is complete

CHANNELS MISMATCHED	D12 D13	DEFECTIVE OR POORLY SOLDERED DEFECTIVE
	D16	DEFECTIVE
	R167	MISSING
	POTS	ADJUSTED
	D14	DEFECTIVE
	C101	WRONG VALUE
	C191	MISSING
	U26	DEFECTIVE
CHANNELS SCRAMBLED	JACK	POORLY SOLDERED
COLOR	R503	MISSING OR POORLY SOLDERED
COMPOSITE FLICKERS	Q30	POORLY SOLDERED
	POTS	ADJUSTED
	Q31	DEFECTIVE
COMPOSITE NO VIDEO	Q15	POORLY SOLDERED OR REVERSED
	L6	POORLY SOLDERED
FLICKERS	R503	MISSING
FREQUENCY	Y1	DEFECTIVE
LED	LED	DEFECTIVE, POORLY SOLDERED OR REVERSED
NO POWER/VCC SHORT	C146	POORLY SOLDERED
	SW1	POORLY SOLDERED OR TRACE DAMAGED
	C222	POORLY SOLDERED
	C284	POORLY SOLDERED
	1.24	DEFECTIVE
	R80	POORLY SOLDERED
NO VIDEO	1.22	DEFECTIVE
	U31	POORLY SOLDERED
	1.4	DEFECTIVE
	Y1	DEFECTIVE
SOURCE MENU BLANK	U31	POORLY SOLDERED
SOURCE MENU FLICKERS	U31	POORLY SOLDERED

OURCE MENU SCRAMBLED	U31	POORLY SOLDERED
	U30	POORLY SOLDERED OR TRACE DAMAGED
	U27	POORLY SOLDERED
	U35	DEFECTIVE, POORLY SOLDERED OR TRACE DAMAGED
	Y4	DEFECTIVE
	U34	POORLY SOLDERED
AKE BAR	RV6	DEFECTIVE, LOOSE OR POORLY SOLDERED
	POTS	ADJUSTED
	C242	POORLY SOLDERED
HUMBNAILS CHECKERED	C201	DEFECTIVE OR POORLY SOLDERED
HUMBNAILS COLOR	JACK	DEFECTIVE OR POORLY SOLDERED
	Q31	DEFECTIVE, MISSING OR POORLY SOLDERED
HUMBNAILS MISSING	Q30	DEFECTIVE, MISSING OR POORLY SOLDERED
	JACK	POORLY SOLDERED
	Y3	DEFECTIVE
	D17	DEFECTIVE, MISSING OR REVERSED
	D16	DEFECTIVE
	Q31	DEFECTIVE OR MISSING
1	U27	DEFECTIVE
	C201	MISSING OR POORLY SOLDERED
		pris per per per pas march 3 per
HUMBNAILS ROLL	U27	DEFECTIVE
HUMBNAILS SCRAMBLED	JACK	POORLY SOLDERED
C COLOR	JACK	DEFECTIVE OR POORLY SOLDERED
C FLICKERS	Q30	DEFECTIVE OR POORLY SOLDERED
	POTS	ADJUSTED
	Q31	DEFECTIVE
C NO VIDEO	JACK	POORLY SOLDERED
	Q18	MISSING
C SCRAMBLED	JACK	POORLY SOLDERED

Mixer Father Board Tune Up Procedure PROC-0055-01 Revision A; 02/27/95

 Connect the Y/C cable to the Video In 1 connector, top most connector (J7) and all the RCA composite cables to all other composite inputs.

 Connect the composite RCA cable from Monitor Input B to the Preview Video output, bottom most yellow connector J1.

 Attach the keyboard cable to the socket connector on the main pcb at JP3. The red and brown wires must be oriented to the right.

3. Initialization:

3.1. Power on the Mixer under test. The power, audio, video, and "A" LEDs should come on, the "B" LED should blink off and on. The Videonics Mixer "Splash Screen" will be displayed momentarily then the Mixer "Control Panel" will be displayed on the Preview output, (Monitor video input "B") which is the only output connected for Tune-Up.

3.2. Check the "thumbnail" (small video image) in all four windows across the top of the display. Insure that they are the correct color and

brightness, and none are flashing or missing.

4. MX1 Father Board Tune Up:

4.1. Adjust 13.5Mhz clock:

4.1.1. From the frequency counter, clip the probe tip on pin 8, U28 and the

black ground alligator clip to GND test point (TP26).

4.1.2. Adjust the variable capacitor CV1 until the frequency is 13,500,000 (13.5Mhz) +/- 100hz. Caution: if the frequency counter doesn't change as you rotate the alignment tool, it's probably because the blade on the alignment tool is too short, and you aren't actually moving the variable caps moving plate.

4.1.3. Power cycle the Mixer under test, insure that the frequency

adjustment hasn't changed.

 Insure that the video thumbnails are still correct color, no flashing or black and white.

4.1.5. Disconnect the frequency counter test probe from the main pcb.

4.2. Adjust Chroma channels:

4.2.0.1. Enter the manufacturing test menu by pressing and holding the following keys simultaneously: <SHIFT>,<FLIP>, and <AUDIO/VIDEO>. The Top Level MFG Test Menu will appear.

4.2.0.2. The top level MFG Test Menu has three options, [01], [02], and [03].

4.2.0.3. From the Top Level MFG Test Menu select option [01], by using the four way cursor positioning key (Diamond Key). When the cursor is on the [01] option press the <OK> key.

Mixer Father Board Tune Up Procedure PROC-0055-01 Revision A; 02/27/95

1. Equipment:

1. Composite Video sources:

SOURCE 1 (Y/C & Composite):

For PAL: TM2000 with set up as following:

 Background: Lightest Gray Background with the control color bars set up as indicated- Hue (top bar) at 000, Saturation (middle bar) at 000, and lightness (bottom bar) at 150.*

Font: Block (the fourth down from Menu).
 Size: Biggest (the right most size selection).

 Title: Darker Gray letters P, R, B (Hue:000, Saturation:000, Lightness:100) with Black outline and box.

For NTSC: TM2000 with set up as following:

 Background: Blue background (default color palette selection)* with the control color bars set up as indicated. Hue at 80, Saturation at 120, and lightness at 30.

. Font: Block (the fourth down from Menu).

Size: Biggest (the right most size selection).

 Title: Darker Grey letters P, R, B (Hue: 000, Saturation: 000, Lightness: 100) with lighter Grey outline and box (Hue: 000, Saturation: 000, and Lightness: 150).

 BOURCE 2 (Composite): TM2000 with "horizonts!" color ber output (selected from MFG Test Menu).

 c. SOURCE 3 (Composite): TM 2000 with Solid RED Background output (the third Red down from background color palette (Hue:195; Saturation:145, Lightness:050)).

d. SOURCE 4 (Composite): TM 2000 with Solid GREEN Background output (the first Green from background color palette (Hue:102, Saturation:151, Lightness:61)).

Frequency counter (8 digits) with Test Probe (X1).

3. Video monitor with composite input. Recommended SONY PVM 1344Q.

Note that all input sources should have nominal Subcarrier frequency (14,31818MHZ for NTSC & 17.734475MHz for PAL, +/- 100 Hz).

* Press <SHIFT>, <COMMAND> and <UNDO> keys simultaneously to get into MFG Test Menu. Select "Reset Database" then press <OK> to clear all previous memories. Use the Up/Down cursor to select Exit Menu then proceed the set up procedure for T2000. Refer to TM2000 Instruction Manual (chapter 14) for more details.

2. Cable Hookup:

2.1. Install the board onto the test fixture.

